



**Use Brief Introduction**

The circuit inside the lightning event counter used together with the power lightning protector has been connected. When use, just switch on the power according to the positive and negative poles (+ -) showed on the lightning event counter.

Batteries supply power for lightning event counter used independently. When installed, connect the sampling detector according to the user's guide, and distance from the lightning event counter to the tested end should be less than 50 meters. Batteries should be checked 1~2 times per year, please change the batteries in time when power not enough.